

Anziehvorschrift Zylinderkopf

Tightening Instructions for Cylinder Head

Instructions de serrage pour culasse

Prescripciones de apriete para culatas

374.906


passend für / suitable for
adaptable à / adaptable a

FORD USA




Das Original

Schraubenkopf / Head shape Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete
Tête de vis / Cabeza de tornillo



755.570

M 11x1,5x131,5



Anziehen/
Tightening/
Serrage/
Apriete

- 20Nm / 14,7 lbft
- 35Nm / 25,8 lbft
- 90°
- 90°
- 90°

M8: 11Nm / 8 lbft

Zeichenerklärung / Explanations / Explication / Explicacion

●	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
*	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

V6 227cid 3.7l DOHC 24V / RH

∅: 97,3mm ÷: ∅,89mm

Elring-Serviceteam

Fon +49 7123 724 799

Fax +49 7123 724 798

service@elring.de

24/11/12

374.906