

Anziehvorschrift Zylinderkopf

Tightening Instructions for Cylinder Head

Instructions de serrage pour culasse

Prescripciones de apriete para culatas

012.361

passend für / suitable for
adaptable à / adaptable a

Renault / Nissan




Das Original

Schraubenkopf / Head shape Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete
Tête de vis / Cabeza de tornillo



759.350
M 9x1,25x103



Anziehen/
Tightening/
Serrage/
Apriete

1. 20 Nm
 $90^{\circ} \pm 6^{\circ}$
 3 min
Pos. 1/2:
 20 Nm
 $200^{\circ} \pm 6^{\circ}$

2. Pos. 3/4/5/6:
 20 Nm
 $200^{\circ} \pm 6^{\circ}$
Pos. 7/8/9/10:
 20 Nm
 $200^{\circ} \pm 6^{\circ}$

Zeichenerklärung / Explanations / Explication / Explicacion

	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
	Setzzeit	relaxation time	durée de tassement	tiempo de espera
	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

÷ 1,27 mm, Ø 70 mm

Mot.: D7D 700/740, D7F 700-704/706/710/720/
722/726/730/744/746/764/766

Clio, Kangoo, Twingo
Kubistar

Elring-Serviceteam

Fon +49 7123 724 799

Fax +49 7123 724 798

service@elring.de

24/11/12

012.361