

Front Coil Springs Orientation

Audi, Seat, Skoda, Volkswagen

When replacing front coil springs on the above vehicles, it is important to install them the right way up.

Incorrect installation can cause the spring to bend, or move out of position and rub against the bodywork.

The **ROUND** end (see diagram) should be installed in the **TOP** bearing.
The **OVAL** end (see diagram) should be installed in the **BOTTOM** spring pan.

Round End

Correct Orientation



Oval End

Ausrichtung der vorderen Schraubenfedern

Audi, Seat, Skoda, Volkswagen

Beim Austausch der vorderen Schraubenfedern an den oben genannten Fahrzeugen ist es wichtig, diese richtig zu montieren.

Eine falsche Montage kann dazu führen, dass sich die Feder verbiegt oder sich in eine andere Position bewegt und an der Karosserie reibt.

**Das runde Ende (siehe Diagramm) sollte im oberen Federbeinlager montiert werden.
Das ovale Ende (siehe Diagramm) sollte in den unteren Federteller gesetzt werden.**

Rundes Ende

Richtige Ausrichtung



Ovales Ende