



WICHTIGER MONTAGEHINWEIS

STT Bremsleitungsverbinder



- Für 4,75 mm Kupfer-, Kupfer-Nickel und Stahl Bremsleitungen
- Doppelkonus-Schneidring
- Montage ohne Bördelung
- Keine Überwurfschrauben
- Drucktest über 600 Bar

Einbauempfehlung:

Schritt 1

- Bremsleitung durchtrennen und beide Endstücke säubern.
- Bremsleitung entsprechend Bild bis zum Anschlag einstecken



Schritt 2

- Überwurfmuttern per Hand festziehen
- Mittelteil mit 11er Maulschlüssel festhalten
- Zum Abschluss beide Muttern jeweils eine $\frac{3}{4}$ Umdrehung anspannen





IMPORTANT INSTALLATION NOTICE

STT Adapter, brake lines (Union Nut)



- Suitable for 4.75mm copper-, copper-nickel and steel brake lines
- Double-cone cutting ring
- Fitting without flanging
- No sleeve nuts
- Pressure test above 600 bar

Fitting recommendation:

Step 1

- Cut the brake line and clean both ends
- Push the brake line to the stop as shown on the picture



Step 2

- Tighten the union nuts by hand
- Hold the middle part using an 11 mm open-end spanner
- Finally tighten both nuts with a three-quarter turn

