

# SKF Technik Bulletin

## VKBA 7213



BMW 1 (F20/21), 2 Cabrio (F23), 2 Coupe (F22, F87), 3 (F30, F80),  
3 Gran Turismo (F34), 3 Touring (F31), 4 Cabrio (F33, F83), 4 Coupe (F32, F82),  
4 Gran Coupe (F36)



Verwenden Sie ausschließlich die in den Radlager-Kits enthaltenen Schrauben!



SKF Kit	OE Nr
VKBA 7213	31 20 6 794 850, 31 20 6 857 230, 31 20 6 867 256, 31 20 6 876 840

Der o.g. Radlagersatz wird mit vier Befestigungsschrauben am vorderen Achsschenkel montiert. Bei der Montage des neuen SKF Radlagers VKBA 7213 ist es **zwingend erforderlich**, die mitgelieferten Schrauben **M12 X 1,25** zu verwenden, damit die Gewindesteigungen der Befestigungsschrauben und des Radlagers übereinstimmen.

### VKBA 7213



**Gewinde: M12x1,25**

### Beachten Sie immer die Montageanleitung:

- Es wird empfohlen, die Schrauben zunächst von Hand zu montieren und anschließend mit einem Drehmomentschlüssel auf das angegebene Drehmoment anzuziehen
- Verwenden Sie zum Anziehen der Schrauben niemals einen Schlagschrauber
- Beachten Sie stets das vom Fahrzeughersteller vorgegebene Anzugsdrehmoment

**ACHTUNG: Die Verwendung falscher Schrauben führt zur Zerstörung der Gewinde**

**YouTube** [Click here to watch SKF technical videos on Youtube](#)

The contents of this publication are the copyright of the publisher and may not be reproduced (even extracts) unless written permission is granted. Every care has been taken to ensure the accuracy of the information contained in this publication, but no liability

QR code

